

DOME FRESH

WALL MOUNTED AIR FRESHENER

*For Professional Use Only
 Consult the label and MSDS before using*

FRESHENS CONSISTENTLY FOR 30 DAYS, EFFICIENT - COMPUTER PROGRAMED, CAN'T SPILL OR MISFIRE - SAFE FOR YOU & YOUR FACILITY, 100% RECYCLABLE, AUDIBLE ALERT, MADE IN THE U.S.A., EASY TO USE, MOTOR DRIVEN FAN, 2-3 TIMES MORE FRAGRANCE THAN GELS OR METERED AEROSOLS.

PRODUCT NUMBER:

- 9003 - Dome Fresh Dispenser
- 5072 - Dome Fresh Island Berry
- 5073 - Dome Fresh Mango Tango

DESCRIPTION:

Dome Fresh – the cover is the air freshener! Dome Fresh is the world's only air freshener dispenser that uses the fragranced cover of the dispenser as the air freshener refill itself! Now, instead of unlocking a dispenser, unloading the old refill, loading the new refill and replacing the refill, you just take off the old cover/refill and replace it with a FRESH one!!! Made in the U.S.A.

Freshens consistently for 30 days The Dome Fresh fragranced cover is composed of a unique material containing 2-3 times more fragrance than gels or metered aerosols. The motor-driven fan moves fragrance further than a typical passive system, thus freshening larger areas. The smart system behind the Easy Fresh releases approximately the same amount of air freshener daily over 30 days by turning the fan sparingly in week 1, and gradually turning it more frequently until week 4 when the fan runs constantly. The smart dispenser comes with a light that alerts you to change your cover after 30 days, and begins counting down another 30 days once you change the cover!

DIRECTIONS FOR USE:

Easy to Use: This smart dispenser remembers everything so you don't have to! Replacing the cover activates a 33 day computer program with the following prompts:

- **Days 1-29:** green LED flashes indicating 'all systems go'
- **Day 30+:** red LED flashes indicating 'time to change cover'
- **Day 33+:** red LED flashes plus audible alert sound every 3 ½ minutes.

Mounts to any flat surface with the double-sided tape or screw kit that is included.

Computer Program controls fan activation.

Audible Alert beeps every 3 ½ minutes starting on day 33.


Light Sensor detects when the room is not in use to conserve battery life.

Fan turns sparingly in week 1, and gradually turns more frequently until week 4 when the fan turns constantly.

Battery - alkaline "C" size

LED signals **Green** (ok) or **Red** (replace).

Push Tab makes it easy to remove the old cover.



ADDITIONAL INFORMATION:

Helpful Hint: Rotate your fragrances! Fragrance fatigue ("I can't smell it anymore!") is a real physiological response to constant exposure to one fragrance. For best results, make sure you change fragrances every month.

- Efficient – the fan only turns when the lights are on.
- The Dome Fresh reminds you when to service it.
- Can't spill or misfire – safe for you and your facility.
- 100% recyclable, and easily recycled.
- Part of the industry's first closed-loop recycling program.



DOME FRESH